Folding Chair

White plastic folding chair with steel frame for events, catering and gardens



Folding chair

A sturdy folding chair with a powder-coated steel frame and a seat and backrest made of UV-stabilised HDPE plastic. It is weather-resistant, easy to clean and folds flat in seconds for transport and storage.

Size (open)	51 × 47 cm, height 87 cm
Seat height	44 cm
Max. load	130 kg
Frame	steel
Seat, backrest	UV-stabilised HDPE plastic, white
Sets	1, 4 or 8 pieces

Package contents

- Folding chair(s) according to the ordered set (1, 4 or 8 pieces), fully assembled – no tools needed

Unfolding, folding and use

1. **Unfold**
   Stand the folded chair upright. Hold the backrest with one hand and push the seat down with the other until it is fully horizontal.
2. **Check**
   Make sure the seat is fully down and the chair stands firmly on all four legs before anyone sits on it.
3. **Sit**
   Sit down in the middle of the seat. The chair is designed for one person up to 130 kg.
4. **Fold**
   Lift the front edge of the seat upwards until the chair is completely flat. Keep your fingers away from the joints.
5. **Store**
   Lean the folded chairs against each other or a wall, or stack them lying flat. Store in a dry place.



Folded chairs take up little space



Ready to use outdoors

⚠ Safety instructions

For this product

- Maximum load 130 kg – one person only. Do not stand, kneel or jump on the chair.
- Do not use the chair as a ladder or step stool.
- Do not rock or lean back on the rear legs – the chair can fold or tip over.
- Risk of pinching: keep fingers away from the joints when folding and unfolding.
- Do not sit on the backrest or on the front edge of the seat only.

General

- Use only on a firm, level and dry surface. Do not use on soft, uneven or slippery ground.
- Before every use, check the frame, joints, rivets and plastic parts. Do not use damaged or deformed furniture.
- Keep children away when folding and unfolding, and do not let them play with the furniture.
- Keep away from open fire, grills, heaters and other heat sources.
- Secure the furniture in strong wind – folded or light furniture can be blown away.

Care and storage

- Clean with water and mild soap. Do not use solvents or abrasive cleaners.
- Let the chairs dry before folding and storing them.
- Store in a dry place. Although the plastic is UV-stabilised, long storage in direct sunlight is not recommended.

The manufacturer is not liable for damage or injury caused by overloading, improper use, use on unsuitable ground or by not following these instructions.